




USB to UART interface

Self Powered Config: R30 4.7k / R31 10k / R32 0R / Filter1 not inserted

Bus Powered Config: R30 N.i. / R31 N.i. / R32 N.i. / Filter1 & R33 inserted (no separate power supply possible!)



RS232 to TTL



Ausgabe - Issue:	<unbekannt>	Zeichner	<unbekannt>	Blatt	1
Änderung	18.04.17	16-46	Interface-Shield		
Ausgabe	18.04.17	17-15			
Datei	ergoLINK_shield_rev20170418.T300	Projekt	<unbekannt>		